

ConduFlow

MIXING INSTRUCTIONS

Step 1.

Acquire a corded high torque drill for mixing and grout mixing paddle – Quick-Mix Mixer Model 819 or similar.

Step 2.

Open the pail and mix the ConduFlow liquid backfill for 1 to 2 minutes until smooth consistency.

Step 3.

While mixing ConduFlow, slowly add the Curing Agent.
Continue mixing ConduFlow and the Curing Agent for an additional 2-3 minutes.

Step 4.

Use the ConduFlow liquid backfill within 10 minutes of adding the curing agent

Storage Instructions:

Do not store below 5°C / 41°F.
Can be used in temperatures below 5°C / 41°F if stored in warm location before use.
Do not open lid until ready to use.
Shelf life before adding curing agent =12 months.

PLACING INSTRUCTIONS

Hole/Trench

Pour ConduFlow into hole or trench, ensuring that no air is entrapped.

Canister Anode

Pour 1 pail of ConduFlow into hole before placing Canister Anode.
Place Canister Anode into hole.
Pour remaining pails of ConduFlow around the anode, carefully ensuring no air is entrapped.

ConduDisc

Pour 1 pail of ConduFlow into hole.
Lower utility pole with mounted ConduDisc to bottom of hole.
Backfill as usual.

Curing Instructions:

Do not turn on impressed current systems for a minimum of 28 days after installation.
ConduFlow sets in 24 hours, full cure in 28 days.