# ConduFlow

# MIXING INSTRUCTIONS

### Step1.

Acquire a corded high torque drill for mixing and grout mixing paddle – Quick-Mix Mixer Model 819 or similar.

# Step 2.

Open the pail and mix the ConduFlow liquid backfill for 1 to 2 minutes until smooth consistency.

### Step 3.

While mixing ConduFlow, slowly add the Curing Agent.
Continue mixing ConduFlow and the Curing Agent for an additional 2-3 minutes.

#### Step 4.

Use the ConduFlow liquid backfill within 10 minutes of adding the curing agent

# **Storage Instructions:**

Do not store below  $5^{\circ}\text{C}$  /  $41^{\circ}\text{F}$ . Can be used in temperatures below  $5^{\circ}\text{C}$  /  $41^{\circ}\text{F}$  if stored in warm location before use. Do not open lid until ready to use. Shelf life before adding curing agent =12 months.

# PLACING INSTRUCTIONS

#### Hole/Trench

Pour ConduFlow into hole or trench, ensuring that no air is entrapped.

## Canister Anode

Pour 1 pail of ConduFlow into hole before placing Canister Anode.

Place Canister Anode into hole.

Pour remaining pails of ConduFlow around the anode, carefully ensuring no air is entrapped.

#### ConduDisc

Pour 1 pail of ConduFlow into hole. Lower utility pole with mounted ConduDisc to bottom of hole. Backfill as usual.

## **Curing Instructions:**

Do not turn on impressed current systems for a minimum of 28 days after installation. ConduFlow sets in 24 hours, full cure in 28 days.



