



ConduRod Installation Procedure

Distribution Pole Installation

1. Install distribution pole as per utility standard.
2. Before backfilling, place ConduRod vertically in pole hole.
3. Connect ground wire to ConduRod.
4. Backfill distribution pole as per utility standard.

Alternative ConduRod Installation

1. Prepare hole with a minimum depth of six feet (1.8 m) and minimum diameter of six inches (15 cm).
2. Place ConduRod vertically in hole.
3. Backfill with native soil. Where sandy or rocky soil backfill exists, SAE recommends ConduCrete be used as an alternative to ensure expected performance.
4. Connect ground wire to ConduRod.

Published Date: April 2023